



New Battery Information for the MMPD-8K

Battery type: 12 volt Lithium Ferro Phosphate Battery (LiFePO₄) and is recyclable (CE Compliant)

Part Number: PDBAT-1114 LiFePO₄ Battery and terminal protector

Part Number: PDBATS-1113 LiFePO₄ Battery, AC Charger and terminal protector

Part Number: PDBATC-1124 AC Charger for LiFePO₄ Battery

Important: Batteries are shipped with less than 25% charge and **MUST** be charged for 4 hours before operating

Caution: Batteries can only be charged with the PDBATC-1124 battery charger use of any other type will damage the battery.

LED indicator on Charger

- Red= Charging
- Green= Charged

Depending upon environmental conditions and age battery should last up to 30 hours on a full charge.

If the battery is in the MMPD-8K base while charging the base unit will NOT function.

NOTE 1: Battery has built in circuitry to protect the cells from being drained completely reducing battery life.

When the battery voltage is below 10 volts the circuitry will disconnect the battery from the terminals and no voltage will register.

Once the charger is plugged into the battery and the RED charge light illuminates the circuitry will reset and the voltage will be present on the terminals.

NOTE 2: The terminal protector **MUST** be used to ship the battery as it is classified as equipment so the battery is considered shipped "IN Equipment" for shipping purposes.



SALES/CUSTOMER SERVICE: Middletown, Connecticut, USA

Phone: 508-876-1070 Fax: 508-883-3434 sales@mcgan.com www.mcgan.com